



Candle Burning Instructions

To remove Wick Assembly please grip the **plastic cap** as shown in **View** . Fill tube to about 1/4 inch from the top with **candle oil**. Insert wick assembly with glass tube facing upwards and wick inserted into oil-filled tube. Wick should be nearly flush with top of glass tube. Let wick soak in oil for 2 minutes before lighting. -To adjust flame height, extinguish flame and raise or lower wick height inside glass tube once wick has cooled. This can be done by moving the fiberglass **wick itself** up or down inside the glass tube.

Do not remove the glass tube itself. Only move the wick inside the glass tube. Flame height should be kept to about 1 inch to prevent melting top of candle. Light your candle on top of **glass tube** where wick is thru and enjoy!

Warning: *Use only candle/lamp oil (liquid paraffin oil) when burning your candle. Never use other fuel types! Keep your candle out of reach of children and pets that could knock it over. The oil is not sealed in the candle, If the candle is tipped it will spill!

www.weddingfairytaledreams.com
bill@weddingfairytaledreams.com

www.billscandles.com